



Installation Instructions for FUZE Over Existing Dry Erase Paints

1. **Thoroughly scuff surface.**
 - Use medium grit sandpaper (100 -120 grit)
 - Attempt to achieve lowest profile possible
 - Be certain to remove all gloss
2. **Dry Wipe surface with a clean cloth to remove dust from sanding.**
3. **Prime surface with *Glidden Gripper, Kilz Premium, Sherwin-Williams Multi-Purpose or Zinsser BIN Primer.***
 - Use 3/16" nap roller
 - It is important to "over-roll" the primer application to insure that it achieves a full bond everywhere; apply the primer generously, level it out, back roll, and then rebalance for complete coverage
 - Allow primer to dry as specified in the instructions on the primer can
4. **Sand smooth (lightly) the primed surface.**
 - Use fine grit sandpaper (180 grit)
5. **Dry Wipe surface with a clean cloth to remove dust from sanding.**
6. **Apply FUZE according to installation instructions included in each kit.**