

# Instructions

## For hollow wall thickness 0.125" to 0.500" thick

1. Drill 3/16" dia hole into wall at desired locations
2. Remove screw from anchor
3. Tap-in anchor with hammer into drilled hole until anchor is flush with wall
4. Turn screw into anchor until anchor flairs open and locks onto wall (see photo below).  
Screw will tighten once anchor locks onto wall.
5. Remove screw from anchor
6. Position item to be hung onto wall
7. Fasten item to wall by re-installing screw thru item into anchor

**Back side view of expanded anchor**



**Expanding Hollow Wall Anchor for  
SlatWall**  
P/N: HSL.WA

Any questions or problems, please contact us:

KOFFLER SALES COMPANY  
785 Oakwood Road  
Suite C-100  
Lake Zurich, IL 60047-1524

Toll-Free: 1-888-355-MATS (6287)  
Phone: 1-847-438-1152  
E-mail [info@kofflersales.com](mailto:info@kofflersales.com)

Monday - Friday 8:30 am - 4:30 pm CST



Find more great Garage Gear at  
[www.kofflersales.com](http://www.kofflersales.com)



**Koffler Sales Company**  
Specialists in Floor and Wall Protection  
For Over 50 Years!