

Installation Procedures

*******DO NOT CUT OR WELD VIGIL PRODUCT*******

Stair Tread – Pre drilled – Installed with wood screws – Self-adhesive inserts applied after Stair Tread is securely in place.

Tools : Variable speed drill (electric, pneumatic or battery).
: P-3 driver for drill

Procedure

1. Check all steps and establish if they are all the same configuration. All stair treads are pre-drilled.
2. Starting with the top step, place the stair tread in the desired position on the step.
3. Insert a wood screw onto the P-3 and place pressure into the nosing to hold it in position and activate the drill. Keeping pressure on a very low speed drill, tighten the wood screws.
4. Repeat procedure 3 with the other stair treads.
5. Check that each stair tread is fastened correctly and securely. Ensure that the wood screws are tightened to where the screw heads are flush with the surface. *Make sure the stair treads are clean and free of debris before going to step 6.*
6. Starting again at the top step, remove the protective cover from the self-adhesive inserts and carefully place the inserts onto the stair tread. Apply pressure to make sure there is a good bond with the stair nosing.

Please Note:

- *Barricade off each flight of steps as the stair nosing's are being installed*
- *Ensure that all stair treads are fully secure*
- *Always use appropriate personal protective equipment such as earplugs and safety glasses while performing installation.*