

**G100 Surface Mounted Corner Guard**

1. Apply and secure a bottom cap beginning directly above cove base with appropriate fasteners.
2. Apply continuous retainer to wall directly above bottom cap with appropriate fasteners at 18"(457.2mm) O.C.
3. Install top cap directly above aluminum retainer with appropriate fasteners.
4. Snap precut Korogard cover in position. Cover should be lipped over one edge and pressure applied toward opposite leg from center with a "snap action" movement. Procedure should begin at bottom and be repeated as necessary for full height of cover.
5. Factory cut-to-size products can have a +/- 1/16" variance, we recommend fit and sizing be confirmed before installing.

