



Koffler Sales Company
Specialists in Floor and Wall Protection
For Over 50 Years!
888.355.6287



Dear Valued Customer,

Thank you for your order on www.kofflersales.com. Enclosed you'll find your ordered items. Please use the following instructions to install No-slip Strips

Instructions

Required Tool: Power Screwdriver with P2 Philip bit

Step 1. Place the metal base-strip about 1.5" from edge of step. The label on metal base-strip shows you which side must face the front of step.

Step 2. Set power screwdriver to at least **16Nm** and install retaining screws. The torque setting (16Nm) is very important as it will prevent screws from popping-up when No-slip Strips is in use.

Step 3. Apply peel-n-stick traction tape on top of secured base-strip.



Important Notice to User: Product Use: Our solution balances safety, ease of application, and removal. However there are factors beyond our control and uniquely within user's knowledge and control that can affect the use and performance of No-slip Strips in a particular application. Given the variety of factors that can affect the use and performance of No-slip Strips, user is solely responsible for evaluating No-slip Strips and determining whether it is fit for a particular purpose and suitable for user's method of application. **Warranty: KOFFLER SALES COMPANY MAKES NO EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** Limitation of Liability: **Except where prohibited by law, Koffler Sales Company will not be liable for any loss or damage arising from the use of No-slip Strips, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.**