

## VINPRO-T Molding Installation Instructions

1. To ensure proper support of the lateral crosspiece, ensure the joint width is less than 1/2" (12.5 mm) or 1" (25 mm).
2. The joint cavity must be at least 1/8" (3mm) deep and free of debris. Substances that inhibit adhesion must be removed from the sides of the joint.
3. Fill the joint with elastomeric sealant such as Schluter-KERDI-FIX or similar. Insert the vertical leg of VINPRO-T in the joint so that lateral crosspiece rests completely on the edges of the surface covering.
4. Remove any excess sealant with suitable cleaner.