

# INSTALLATION INSTRUCTION

## Boston Bumper Series 2000®

**Note: Flexible Top: Over cut vinyl ¼" for every 4' section of the flexible top to ensure a proper fit.**

**Note: Rigid Top: Do not over cut.**

### Installation



1. Attach the base and end/corner cap to the desired surface by inserting #8 panhead screws through the pre-slotted holes in both the end cap and the base. Insert screws through the two holes of end cap and tighten.



**2a. Flexible Top:** Butt end of the vinyl top against end/corner cap. While applying pressure with your thumb + forefinger, bend back vinyl top so that vinyl legs are positioned within the base grooves. Roll vinyl top over full length of base, then tap with rubber mallet to ensure vinyl is securely locked into the base.

**2b. Rigid Top:** Snap the Rigid Top over the Rigid



3. If necessary wipe clean with any household cleaning product.

### Tools

- Tape measure
- Power miter saw or radial arm saw
- Drill
- #8 panhead screws
- Screwdriver
- Miter box
- Sand mallet
- Safety goggles

### Helpful Hints

- For best results, before cutting, install a scrap piece of base into vinyl top to achieve a clean cut.
- Set the uncoiled flexible vinyl at room temperature 24 hours prior to installation.
- Lubricate the inside of the vinyl with soapy water or silicone spray before installing.
- Over cut the flexible vinyl and compression fit. Adding the additional material will compensate for stretching which occurs during installation.