

Installation Instructions

Corner Guards with Holes and Screws or Nails

STEP 1

Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust, and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2

Remove the clear protective film on the exposed side of the corner guard.

STEP 3

3/4" WING

Place in desired location and hold the corner guard firmly. Using factory supplied nails, hammer the nail through the corner guard into the wall.

1-1/8"-3" WING

Place in desired location and hold the corner guard firmly. Attach the corner guard by placing the provided self tapping screws in the pre-drilled counter sunk holes and attach to the wall.

Corner Guards with Double Sided Tape*

STEP 1

Wall surfaces must be clean, dry and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust, and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2

Remove the clear protective film on the exposed side of the corner guard (clear corner guards only).

**Self-adhesive corner guards are easy to install, but will break down in high traffic areas more quickly than a corner guard that is fastened with holes and screws.*

STEP 3

Peel off backing tape from one wing entirely, then peel back the tape partially on on the second wing. Place wing with the fully exposed tape to the wall, then remove the remainder of the tape backing from the second wing. Press firmly along the entire length of the corner protector to ensure a good bond.

**Cutting Polycarbonate**

Due to the tough nature of polycarbonate corner guards, Wallprotex does not recommend cutting the corner guards in the field. The corner guard material when cut with a power saw can cause the saw to kick back and injure the operator. For custom lengths call before placing an order and Wallprotex can cut the parts to size in the manufacturing process. If cutting is absolutely required, use a hacksaw and be careful.

**Storage & Handling**

The corner guards are shipped unassembled. Upon receipt, the corner guards should be stored in the horizontal position at room temperature (65 °-75 ° F). This is a finished product; store in a protected, clean and dry area away from direct sunlight.

**Cleaning Instructions****STEP 1**

For best results, the use of liquid cleaners such as "409," "Fantastic," and "Mr. Clean," etc. are recommended. The use of powder cleansers is not recommended. Use of such cleansers can leave residue which is difficult to remove.

STEP 2

Do not use chlorinated or aromatic hydrocarbons, esters, or ketones to clean Wallprotex vinyl products. Avoid the use of heavy degreasers, compounds containing surfactants, and abrasive compounds or cleaning devices.

**Caution**

DO NOT walk on the corner guards.
DO NOT store anything on top of the corner guards.