



Installation Sheet

Air Barrier Installation

Installation tips

Tools you will need



Tape measure



Scissors or knife



Stapler

Splices

For splices in wall cavities, overlap the material 1" - 2" to complete the cavity and tape the seam with Fi-Foil FSK tape.

NOTES:

1. Tape any tears in the material.
2. For metal furring strips, wipe down the metal then use double-sided tape or spray adhesive on the metal before applying the air barrier. Proceed using the same basic procedure as above. This will hold the insulation in place until the wall board is applied.

1. Apply the product flat to the face of the wall, attach the product to the vertical wood studs with a staple every 4" to 8" or with metal framing apply the product with using double sided tape or spray adhesive

2. Overlap layers a minimum of 1" to 2". Tape joints with Fi-Foil FSK reflective tape.

3. Wall outlets- cut the material so that it fits snugly around the outlet. Tape the edge of the material to the box.

Diagram 1



Diagram 2



Diagram 3

