

Dry Erase Wallcovering

Care & Maintenance

As with any product, proper care and maintenance is essential to maintain its original functionality and aesthetics and can help extend the useful life of dry erasable materials.

For best performance, MDC Dry Erase wallcovering should be cleaned on a regular basis, daily if necessary, depending upon amount of use. Low Glare Dry Erase will require more frequent cleaning than the higher gloss wallcovering. As with any dry erase surface, residue may build up on your board over time. If erasing becomes difficult, clean your board thoroughly.

The following cleaners are recommended to clean the surface:

- Water
- Expo Dry Erase Cleaner

Rinse thoroughly and dry the surface with a clean dry, lint free soft cotton cloth towel. NEVER use abrasive cleaners or wipes on the surface as it may damage the material.

Clean from the bottom of the wall upward. Rinse thoroughly with clean water from the top down using a soft, cotton cloth. Dry surface thoroughly with a dry, lint-free soft cotton cloth.

Care should be taken not to allow excess water to run behind the floor molding or onto the tray or trim. The trim may become discolored and/or permanently damaged from repeated exposure to water.

Stains should be removed as quickly as possible to minimize any possible reaction between the staining agent and the dry erase surface. Immediately remove materials containing colors or solvents to avoid quick-setting stains. Stains which are permitted to set on the surface may cause permanent discoloration.

Markers

MDC recommends the use of MDC Dry Erase markers for best results. Other dry erase markers may be used but should be tested for acceptability before use across the entire writing surface.

For additional information or technical support contact MDC Customer Care at 800-621-4006